



Smart Digital Timer

Setting Current Time:

1. Press and HOLD the "CLOCK" key during this entire procedure.
2. Press the "HOUR" key to advance the hours.
3. Press the "MIN" key to advance the minutes.
4. Press the "DAY" key to advance the day.
5. If any keys are pressed for a prolonged period, the display will advance rapidly.
6. Release the "CLOCK" key once the time and day have been entered. Now the timer is in operation and ready to be programmed. The colon ":" after the hours will continuously flash indicating that the clock is running.

Programming ON/OFF Events:

1. Press the "PROG" key once. TIMER 1 on - - : - - appears.
2. Using the "HOUR" and "MIN" keys enter the desired ON time. By default all days are indicated. See block programming below for selecting different days. When complete press the "PROG" key once.
3. Timer OFF --:-- will be displayed. Using the "HOUR" and "MIN" keys enter the desired OFF time. By default all days are indicated. See block programming below for selecting different days. When complete press the "PROG" key once.
4. If complete press the "CLOCK" key to return to current time and day.
5. Note that a total of 7-ON and 7-OFF events can be programmed.

Manual Override:

Pressing the door will override the timer setting and will manually turn the switch ON and OFF.

MEMORY BACKUP:

This timer is equipped with a rechargeable Ni-Mh battery which will protect your programs during power failure for up to 30 days.

No need to replace battery.

Note that the screen blanks if the battery is discharged completely.

Block Programming:

1. When programming ON/OFF events, all days are indicated by default. To change the day selection simply keep pressing the Day key and the display will change as follows:
2. Individual Day (MON, TUE, etc.)
3. MON~FRI; SAT~SUN; MON~SAT; MON~SUN
4. MON~WED~FRI; TUE~THU~SAT
5. MON~WED; THU~SAT
6. Follow the steps above to complete programming.

Reviewing Programs:

1. To review the programs that have been entered, press and release the "PROG" key. Each time you do this you will be able to scroll thru the programs.
2. Any program can be edited by pressing the "HOUR", "MIN", and "DAY" keys. Then press the "PROG" key in order to accept the changes.
3. When complete press the "CLOCK" key to return to current time and day.

Deleting Programs:

1. To delete a particular program simply press the "PROG" key until the desired program is displayed.
2. Then press the "HOUR" and "MIN" keys until --:-- is displayed. Then press the "PROG" key in order to delete this particular program.
3. When complete press the "CLOCK" key to return to current time and day.

